



- 14. 장치봉9 (#9 SET BATTEN)
- 13. 끝막 (DRAW CURTAIN) - DISABLE
- 12. 장치봉8 (#8 SET BATTEN)
- 11. 하늘막상단조명 (SKY CYC. LIGHT)
- 10. 조명봉3 (#3 LIGHT BATTEN)
- 09. 장치봉7 (#7 SET BATTEN)
- 08. 조명봉2 (#2 LIGHT BATTEN)
- 07. 장치봉6 (#6 SET BATTEN)
- 06. 장치봉5 (#5 SET BATTEN)
- 05. 조명봉4 (#1 LIGHT BATTEN)
- 04. 장치봉4 (#4 SET BATTEN)
- 03. 장치봉3 (#3 SET BATTEN)
- 02. 장치봉2 (#2 SET BATTEN)
- 01. 장치봉1 (#1 SET BATTEN)